Technical Data Sheet



CDF® Mesh Prep No. 25

A ready-to-use liquid mordant that promotes fabric water retention and, thus, the uniform adhesion of CDF® Direct-Films.

CDF Mesh Prep is especially helpful for use with thin CDF® Direct-Films applied to fine fabric, which inherently holds little water. CDF Mesh Prep rinses easily from the screen with hot or cold water. Non-caustic – will not harm frames, fabric or adhesives on stretch and glue frames. *Recommended for use with CDF*® *Direct-Films. Do not use on natural silk.*

INSTRUCTIONS:

Apply CDF Mesh Prep No. 25 only after the fabric has been thoroughly degreased and immediately before adhering the CDF® Direct-Film.

Rinse both sides of the screen thoroughly with water. Apply CDF Mesh Prep No. 25 with a medium-stiff, long bristle Nylon brush to both sides of the screen. Let the screen stand for one or two minutes.

Rinse the screen thoroughly from both sides with hot or cold water.

CDF Mesh Prep No. 25 should be used no more than one hour before adhering the firm. If you do not proceed immediately to adhere the CDF® Direct-Film, re-wet the screen just before adhering the film.

HEALTH AND SAFETY INFORMATION:

CDF® Mesh Prep No. 25 contains a mild acid and may be irritating over a prolonged period of time if it comes in contact with the skin or eyes.

FIRST AID: In case of contact with the eyes or skin, flush immediately with water for 15 minutes and contact a physician.

PACKAGING:

1 quart=946 ml

1 gallon=3.785 liters

5 gallons=18.925 liters